

To activate Current Source: place Jumpers between HT\_1 and HT\_6, and between HT\_4 and HT\_5  
 To activate Voltage Source: place Jumpers between HT\_1 and HT\_2, and between HT\_3 and HT\_5

